



ASAM

Association for Standardisation of
Automation and Measuring Systems

ASAM MCD-1 (XCP)

Universal Measurement and Calibration
Protocol

Protocol Layer Specification

Version 1.5.0

Date: 2017-11-30

Base Standard

© by ASAM e.V., 2017

Disclaimer

This document is the copyrighted property of ASAM e.V.
Any use is limited to the scope described in the license terms. The license terms can be viewed at www.asam.net/license

Table of Contents

1	<u>Foreword</u>	9
2	<u>Introduction</u>	10
3	<u>Relations to Other Standards</u>	12
3.1	Backward Compatibility to Earlier Releases	12
3.1.1	The XCP Protocol Layer Version Number	12
3.1.2	The Compatibility Matrix	12
3.2	References to other Standards	13
3.2.1	CCP and XCP	13
4	<u>XCP Features And Concepts</u>	14
4.1	Synchronous Data Transfer	14
4.1.1	DAQ, STIM and ODT	14
4.1.2	ODT Entry	14
4.1.3	Object Descriptor Table	15
4.1.4	DAQ List	15
4.1.5	Event Channels	16
4.1.6	Dynamic DAQ Configuration	18
4.1.7	DAQ Configuration Storing and Power-up Data Transfer	23
4.1.7.1	DAQ Configuration Storing Without Power-up Data Transfer	23
4.1.7.2	DAQ Configuration Storing With Power-up Data Transfer (RESUME Mode)	24
4.1.8	DAQ List Prioritization	26
4.1.9	ODT Optimization	26
4.1.10	DAQ Packed Mode	28
4.1.10.1	DAQ List Behavior	29
4.1.10.2	Event Channel	29
4.1.10.3	Timestamps	29
4.1.10.4	Error Handling	30
4.1.11	Bitwise Stimulation	30
4.1.12	Synchronous Data Acquisition	31
4.1.13	Synchronous Data Stimulation	32
4.2	Measurement Modes	34
4.2.1	Polling	34
4.2.2	Synchronous Data Transfer, DAQ direction, Burst, Standard	35
4.2.3	Synchronous Data Transfer, DAQ direction, Burst, Improved	36
4.2.4	Synchronous Data Transfer, DAQ direction, Alternating	37
4.3	Bypassing	38
4.3.1	Delayed Bypassing	38
4.3.2	Bypass Activation	38
4.3.3	Bypassing Startup	39
4.3.4	Plausibility Checks	39
4.3.5	Bypassing Consistency	39
4.3.5.1	Event Channel Relations	39
4.3.5.2	DTO CTR Event Channel Properties	40
4.3.5.3	DTO CTR Field	41

4.3.5.4	DTO CTR Check	42
4.3.5.5	Examples	42
4.3.6	Minimum Separation Time	47
4.4	Online Calibration	48
4.4.1	SECTOR, SEGMENT and PAGE	48
4.4.2	Logical Layout: SEGMENT	49
4.4.3	Accessibility - PAGE	49
4.4.4	Calibration Data Page Switching	50
4.4.5	Calibration Data Page Freezing	51
4.4.6	Addressing Action	51
4.4.7	Master-Slave Action	52
4.4.8	Page-Page Action	52
4.5	Flash Programming	52
4.5.1	Physical Layout: SECTOR	52
4.5.2	General	53
4.5.3	Absolute Access Mode - Access by Address	54
4.5.4	Functional Access Mode - Access by Flash Area	54
4.5.5	Checksum Control and Program Verify	56
4.5.6	End of Flash Session	56
4.6	Time Correlation	56
4.6.1	Introduction	56
4.6.2	XCP Slave's Clock Subsystem	58
4.6.2.1	Scenario 1: one observable clock - free running XCP slave clock	58
4.6.2.2	Scenario 2: one observable clock - single XCP slave clock, synchronized to a grandmaster clock	59
4.6.2.3	Scenario 3: one observable clock - single XCP slave clock, synchronized to a grandmaster clock	60
4.6.2.4	Scenario 4: two observable clocks - free running XCP slave clock combined with a globally synchronized clock	61
4.6.2.5	Scenario 5: two observable clocks - free running XCP slave clock combined with an ECU clock	63
4.6.2.6	Scenario 6: three observable clocks	66
4.6.2.7	Scenario 7: ECU clock only	66
4.7	ECU States	67
4.7.1	Introduction	67
4.7.2	Transferring the State Information to the XCP Master	69
4.7.3	A2L Semantic Consistency	70
4.8	Software Debugging	71
<u>5</u>	<u>The XCP Protocol</u>	<u>72</u>
5.1	Topology	72
5.2	The XCP Communication Models	73
5.2.1	The Standard Communication Model	73
5.2.2	The Block Transfer Communication Model	74
5.2.3	The Interleaved Communication Model	75
5.3	State Machine	76
5.4	Protection Handling	79
5.5	The XCP Message (Frame) Format	80
<u>6</u>	<u>The Limits of Performance</u>	<u>81</u>
6.1	Generic Performance Parameters	81

6.2	DAQ/STIM Specific Performance Parameters	81
6.2.1	DAQ Specific Parameters	82
6.2.2	STIM Specific Parameters	83
6.2.3	ECU Resource Consumptions	83
6.2.3.1	ECU RAM Consumption	83
6.2.3.2	CPU Execution Time	85
7	The XCP Protocol Layer	92
7.1	The XCP Packet	92
7.1.1	The XCP Packet Types	92
7.1.2	The XCP Packet Format	93
7.1.2.1	The Identification Field	93
7.1.2.2	The Counter Field	97
7.1.2.3	The Timestamp Field	98
7.1.2.4	The Data Field	100
7.1.3	The CTO Packets	100
7.1.3.1	Command Packet	100
7.1.3.2	Command Response Packet	101
7.1.3.3	Error Packet	101
7.1.3.4	Event Packet	101
7.1.3.5	Service Request Packet	102
7.1.4	The DTO Packets	102
7.1.4.1	Data Acquisition Packet	103
7.1.4.2	Synchronous Data Stimulation Packet	103
7.1.5	The XCP Packet Identifiers	103
7.1.5.1	Master -> Slave	104
7.1.5.2	Slave -> Master	104
7.2	Event Codes	104
7.3	Service Request Codes	105
7.4	Command Codes	106
7.5	Description of Commands	109
7.5.1	Standard Commands	110
7.5.1.1	Set up Connection With Slave	110
7.5.1.2	Get Version Information	114
7.5.1.3	Disconnect From Slave	115
7.5.1.4	Get Current Session Status From Slave	116
7.5.1.5	Synchronize Command Execution After Timeout	120
7.5.1.6	Get Communication Mode Info	121
7.5.1.7	Get Identification From Slave	123
7.5.1.8	Request to Save to Non-volatile Memory	125
7.5.1.9	Get Seed for Unlocking a Protected Resource	128
7.5.1.10	Send Key for Unlocking a Protected Resource	130
7.5.1.11	Set Memory Transfer Address in Slave	133
7.5.1.12	Upload From Slave to Master	134
7.5.1.13	Upload From Slave to Master (short version)	136
7.5.1.14	Build Checksum Over Memory Range	137
7.5.1.15	Refer to Transport Layer Specific Command	140
7.5.1.16	Refer to User-defined Command	141
7.5.2	Calibration Commands	142
7.5.2.1	Download From Master to Slave	142
7.5.2.2	Download From Master to Slave (Block Mode)	144
7.5.2.3	Download From Master to Slave (Fixed Size)	146
7.5.2.4	Download From Master to Slave (Short Version)	147
7.5.2.5	Modify Bits	148

7.5.3	Page Switching Commands	149
7.5.3.1	Set Calibration Page	149
7.5.3.2	Get Calibration Page	150
7.5.3.3	Get General Information on PAG Processor	151
7.5.3.4	Get Specific Information for a SEGMENT	152
7.5.3.5	Get Specific Information for a PAGE	155
7.5.3.6	Set Mode for a SEGMENT	159
7.5.3.7	Get Mode for a SEGMENT	160
7.5.3.8	Copy Page	161
7.5.4	Data Acquisition and Stimulation Commands	162
7.5.4.1	Set Pointer to ODT Entry	162
7.5.4.2	Write Element in ODT Entry	163
7.5.4.3	Set Mode for DAQ List	164
7.5.4.4	Start/Stop/Select DAQ List	167
7.5.4.5	Start/Stop DAQ Lists (Synchronously)	169
7.5.4.6	Write Multiple Elements in ODT	170
7.5.4.7	Set DAQ List Packed Mode	172
7.5.4.8	Get DAQ List Packed Mode	174
7.5.4.9	Read Element From ODT Entry	175
7.5.4.10	Get DAQ Clock From Slave	176
7.5.4.11	Get General Information on DAQ Processor	178
7.5.4.12	Get General Information on DAQ Processing Resolution	184
7.5.4.13	Get Mode From DAQ List	187
7.5.4.14	Get Specific Information for an Event Channel	189
7.5.4.15	DTO CTR Properties	193
7.5.4.16	Clear DAQ List Configuration	198
7.5.4.17	Get Specific Information for a DAQ List	199
7.5.4.18	Clear Dynamic DAQ Configuration	201
7.5.4.19	Allocate DAQ Lists	202
7.5.4.20	Allocate ODTs to a DAQ List	203
7.5.4.21	Allocate ODT Entries to an ODT	204
7.5.5	Non-Volatile Memory Programming	205
7.5.5.1	Indicate the Beginning of a Programming Sequence	205
7.5.5.2	Clear a Part of Non-volatile Memory	207
7.5.5.3	Program a Non-volatile Memory Segment	209
7.5.5.4	Indicate the End of a Programming Sequence	211
7.5.5.5	Get General Information on PGM Processor	212
7.5.5.6	Get Specific Information for a SECTOR	215
7.5.5.7	Prepare Non-volatile Memory Programming	217
7.5.5.8	Set Data Format Before Programming	218
7.5.5.9	Program a Non-volatile Memory Segment (Block Mode)	220
7.5.5.10	Program a Non-volatile Memory Segment (fixed size)	221
7.5.5.11	Program Verify	222
7.5.6	Time Correlation	223
7.5.6.1	Time Correlation Properties	223
7.6	Communication Error Handling	239
7.6.1	Definitions	239
7.6.1.1	Error	239
7.6.1.2	Pre-Action	239
7.6.1.3	Action	239
7.6.1.4	Error Severity	239
7.6.2	Timeout Handling	240
7.6.2.1	Standard Communication Model	240
7.6.2.2	Block Communication Model	241
7.6.2.3	Interleaved Communication Model	242
7.6.2.4	Time-Out Manipulation	242
7.6.3	Error Code Handling	243
7.7	Description of Events	260
7.7.1	Start in Resume Mode	260

7.7.2	End of DAQ Clearing	260
7.7.3	End of DAQ Storing	261
7.7.4	End of CAL Storing	261
7.7.5	Request to Restart Time-out Detection	261
7.7.6	Indication of DAQ Overload	262
7.7.7	Indication of Autonomous Disconnect	262
7.7.8	Transfer of Timestamp and Synchronization	262
7.7.9	Indication of Timeout at STIM	267
7.7.10	Entering Sleep Mode	268
7.7.11	Leaving Sleep Mode	268
7.7.12	ECU State Changed	268
7.7.13	User-defined Event	269
7.7.14	Transport Layer Specific Event	269
8	<u>Interface to ASAM MCD-2 MC Description File</u>	<u>270</u>
8.1	Overview	270
8.2	ASAM MCD-2 MC AML for XCP (Common_Parameters)	271
8.2.1	Protocol Layer and Transport Layer Parts (XCP_definitions.aml)	271
8.2.2	Combining the Parts to an XCP Communication Stack (XCP_vX_Y.aml)	271
8.2.2.1	Structure of an IF_DATA “XCP”	272
8.2.2.2	Structure of an IF_DATA “XCPplus”	272
8.2.2.3	ASAM MCD-2 MC Description File Containing an IF_DATA “XCP” and “XCPplus”	273
8.3	Example ASAM MCD-2 MC	273
8.3.1	Example of IF_DATA XCPplus	273
8.3.2	Example A2L File	274
8.4	Consistency Between ASAM MCD-2 MC and Slave	274
9	<u>Interface to an External Seed&Key Function</u>	<u>275</u>
9.1	Function XCP_GetAvailablePrivileges	275
9.2	Function XCP_ComputeKeyFromSeed	276
10	<u>Interface to an External Checksum Function</u>	<u>277</u>
11	<u>Interface to an External A2L Decompression/Decrypting Function</u>	<u>278</u>
12	<u>Examples</u>	<u>279</u>
12.1	Configuration Examples	279
12.2	Examples for GET_ID Identification Strings	279
12.3	Example Communication Sequences	279
12.3.1	Setting up a Session	280
12.3.2	Calibrating	283
12.3.3	Synchronous Data Transfer	285
12.3.3.1	Getting Information About the Slave’s DAQ List Processor	285
12.3.3.2	Preparing the DAQ Lists	287
12.3.3.3	Configuring the DAQ Lists	288
12.3.3.4	Starting the Data Transfer	289

12.3.3.5 Stopping the Data Transfer	290
12.3.3.6 Preparing a DAQ List for Packed Mode	290
12.3.4 Reprogramming the Slave	291
12.3.5 Closing a Session	292
12.3.6 Time Correlation	293

13 Symbols and Abbreviated Terms **300**

14 Bibliography **302**

Figure Directory	303
Table Directory	305

1 FOREWORD

XCP is short for Universal Measurement and Calibration Protocol. The main purpose is the data acquisition and calibration access from electronic control units. Therefore a generic protocol layer is defined. As transport medium different physical busses and networks can be used. For each authorized transport medium a separate transport layer is defined. This separation is reflected in standard document structure, which looks like follows:

- One Base Standard
- Associated Standards for each physical bus or network type
- Associated Standard for Software Debugging over XCP

The Base standard describes the following content:

- Protocol Layer
- Interface to ASAM MCD-2 MC
- Interface to an external SEED&KEY function
- Interface to an external Checksum function
- Interface to an external A2L Decompression/Decrypting function
- Example Communication sequences

For each transport layer exist an own associated standard. For the version in hand the following transport layers are defined

- XCP on CAN
- XCP on Ethernet (TCP/IP, UDP/IP)
- XCP on Sxl (SPI, SCI)
- XCP on USB
- XCP on FlexRay

The "X" inside the term XCP generalizes the "various" transportation layers that are used by the members of the protocol family. Because XCP is based on CCP the "X" shall also show that the XCP protocol functionality is extended compared to CCP.