



ASAM

Association for Standardization of
Automation and Measuring Systems

ASAM XIL

Generic Simulator Interface

Part 1 of 5

Programmers Guide

Version 2.2.0

Date: 2020-03-13

Base Standard

© by ASAM e.V., 2020

Disclaimer

This document is the copyrighted property of ASAM e.V.
Any use is limited to the scope described in the license terms. The license
terms can be viewed at www.asam.net/license

Table of Contents

| | |
|--|-----------|
| Foreword | 9 |
| 1 Introduction | 10 |
| 1.1 Overview | 10 |
| 1.2 Motivation | 10 |
| 1.3 What is Hardware in the Loop Simulation | 11 |
| 1.4 Technical Approach | 12 |
| 1.5 Technology Independence | 12 |
| 2 Relations to Other Standards | 14 |
| 2.1 Backward Compatibility to Earlier Releases | 14 |
| 2.2 References to Other Standards | 15 |
| 2.3 Versioning..... | 15 |
| 3 General Concepts | 16 |
| 3.1 XIL Test System Architecture..... | 16 |
| 3.2 Overview Framework | 18 |
| 3.2.1 General..... | 18 |
| 3.2.2 Initialization | 18 |
| 3.2.3 Framework Variables | 18 |
| 3.2.4 Acquisition and Stimulation | 19 |
| 3.3 Overview Testbench..... | 22 |
| 3.3.1 General..... | 22 |
| 3.3.2 Ports of the XIL Testbench API | 22 |
| 3.4 ASAM Data Types..... | 23 |
| 3.5 Instance Creation | 23 |
| 3.5.1 Implementation Manifest File | 24 |
| 3.5.1.1 File content..... | 24 |
| 3.5.1.2 File Naming convention and storage location | 28 |
| 3.5.2 Framework and Testbench Factory..... | 29 |
| 4 Framework | 31 |
| 4.1 Configuration..... | 31 |
| 4.1.1 Framework Configuration File | 31 |
| 4.1.2 Configuring the Framework | 35 |
| 4.1.3 Shutting down the Framework..... | 37 |
| 4.1.4 Customize Automatic port management of the framework | 38 |
| 4.1.5 Object model of the framework configuration | 39 |
| 4.2 Mapping | 41 |
| 4.2.1 Overview | 41 |
| 4.2.2 The Mapping XML Schema..... | 42 |

| | | |
|------------|---|-----------|
| 4.2.2.1 | Identifier Lists | 44 |
| 4.2.2.2 | Framework Label Group..... | 47 |
| 4.2.2.3 | Identifier Mapping | 48 |
| 4.2.2.4 | String Mapping | 50 |
| 4.2.2.5 | Raster Mapping | 51 |
| 4.2.2.6 | Conversion Tables | 51 |
| 4.2.2.7 | Units | 52 |
| 4.2.2.8 | Computation Tables | 54 |
| 4.2.2.9 | Versioning | 55 |
| 4.2.3 | How a Mapping is used by Test Cases | 55 |
| 4.2.3.1 | The Mapping Info API..... | 55 |
| 4.2.3.2 | Identifier Mapping | 57 |
| 4.2.3.3 | String Mapping | 57 |
| 4.2.3.4 | Raster Mapping | 57 |
| 4.2.4 | Tasks of the Framework..... | 57 |
| 4.2.4.1 | Reading mapping XML files | 57 |
| 4.2.4.2 | Consolidating mapping object trees | 57 |
| 4.2.4.3 | Implementing the Mapping Info API | 58 |
| 4.2.4.4 | Resolve the Mapping during Variable Creation..... | 60 |
| 4.2.4.5 | Perform automatic string mappings | 60 |
| 4.2.4.6 | Error handling..... | 60 |
| 4.2.5 | Consistency Rules | 60 |
| 4.3 | Framework Variables | 62 |
| 4.3.1 | What is a Framework Variable | 62 |
| 4.3.2 | Framework variable Classes | 63 |
| 4.3.2.1 | Scalar Variables | 66 |
| 4.3.2.2 | Vector Variables | 67 |
| 4.3.2.3 | Matrix Variables..... | 68 |
| 4.3.2.4 | Curve Variables | 69 |
| 4.3.2.5 | Map Variables | 71 |
| 4.3.3 | Quantities..... | 73 |
| 4.3.3.1 | Scalar Quantity Classes | 74 |
| 4.3.3.2 | Complex Quantity Data Classes | 77 |
| 4.3.3.3 | Usage of Quantities | 79 |
| 4.3.4 | Unit and Physical Dimensions | 82 |
| 4.3.4.1 | Unit Class | 84 |
| 4.3.4.2 | Physical Dimension Class | 84 |
| 4.3.5 | MetaData | 84 |
| 4.3.6 | Calculation with quantity objects | 85 |
| 4.3.6.1 | Overview..... | 85 |
| 4.3.6.2 | Addition and Subtraction | 86 |
| 4.3.6.3 | Multiplication and Division | 86 |
| 4.3.6.4 | Computation Table | 87 |
| 4.3.6.5 | Comparison | 90 |
| 4.3.7 | Data Type Conversion | 90 |
| 4.3.8 | Unit Conversion | 90 |
| 4.3.9 | Usage of Mathematical Operations | 91 |
| 4.3.9.1 | ABSOLUTE and RELATIVE..... | 91 |
| 4.3.9.2 | NEUTRAL UNIT | 91 |
| 4.3.9.3 | Mathematical and Physical Constants | 92 |
| 4.3.9.4 | Example..... | 92 |
| 4.4 | Measuring | 93 |
| 4.4.1 | Motivation | 93 |
| 4.4.2 | Setting up an Acquisition..... | 94 |
| 4.4.2.1 | Introduction..... | 94 |
| 4.4.2.2 | Using the Acquisition Interface | 94 |

| | | |
|------------|--|------------|
| 4.4.2.3 | Acquisition States | 96 |
| 4.4.2.4 | Using the AcquisitionConfiguration Interface | 96 |
| 4.4.2.5 | Principle of Triggered Acquisition..... | 98 |
| 4.4.2.6 | Synchronized Data Acquisition | 102 |
| 4.4.3 | Setting up a Recording..... | 105 |
| 4.4.3.1 | Introduction..... | 105 |
| 4.4.3.2 | Configuring an AcquisitionRecorder..... | 106 |
| 4.4.3.3 | Configuring a Recorder | 106 |
| 4.4.3.4 | Using RecorderResult Readers and Writers | 107 |
| 4.4.3.5 | Working with the Recorded Results | 109 |
| 4.4.3.6 | Recorder States | 111 |
| 4.4.4 | Sequence of Acquisition and Recorder Commands | 112 |
| 4.5 | Stimulation..... | 114 |
| 4.5.1 | Motivation | 114 |
| 4.5.2 | Setting up a Stimulation | 114 |
| 4.5.2.1 | Introduction..... | 114 |
| 4.5.2.2 | Using the Stimulation Interface | 115 |
| 4.5.2.3 | Stimulation States | 115 |
| 4.5.3 | Setting up a Player..... | 116 |
| 4.5.3.1 | Introduction..... | 116 |
| 4.5.3.2 | Configuring a Player..... | 117 |
| 4.5.3.3 | Using a Player | 118 |
| 4.5.3.4 | Player States | 119 |
| 5 | Testbench | 120 |
| 5.1 | Common Functionalities..... | 120 |
| 5.1.1 | ValueContainer | 121 |
| 5.1.1.1 | Overview..... | 121 |
| 5.1.1.2 | General Value Container Classes | 121 |
| 5.1.1.3 | Specific Value Container Classes | 123 |
| 5.1.2 | Document Handling..... | 124 |
| 5.1.3 | Script..... | 125 |
| 5.1.3.1 | Overview..... | 125 |
| 5.1.3.2 | States of Script | 126 |
| 5.1.3.3 | Script Parameters..... | 130 |
| 5.1.4 | TargetScript | 131 |
| 5.1.4.1 | Overview..... | 131 |
| 5.1.4.2 | Parameters | 132 |
| 5.1.4.3 | Custom Properties..... | 132 |
| 5.1.4.4 | Usage of TargetScript | 132 |
| 5.1.5 | Signal Descriptions | 134 |
| 5.1.5.1 | General Remarks about Segment-Based Signals | 137 |
| 5.1.5.2 | Signal Segments | 140 |
| 5.1.5.3 | Converting SignalDescriptions to sample based representations ... | 160 |
| 5.1.5.4 | Using Signal Descriptions | 161 |
| 5.1.5.5 | Signal Description File..... | 167 |
| 5.1.5.6 | Usage of Parameterized SignalDescriptions..... | 168 |
| 5.1.6 | SignalGenerator..... | 171 |
| 5.1.6.1 | Interpretation of SignalDescriptions by the SignalGenerator | 172 |
| 5.1.6.2 | Parameters | 176 |
| 5.1.6.3 | Custom Properties..... | 176 |
| 5.1.6.4 | Usage of SignalGenerator (Stimulating Model Variables) | 176 |
| 5.1.7 | Document Handling for SignalGenerator and SignalDescriptionSet ... | 178 |
| 5.1.8 | Watcher | 181 |
| 5.1.8.1 | General..... | 181 |
| 5.1.9 | Duration | 182 |

| | | |
|------------|---|------------|
| 5.1.10 | Meta Info | 183 |
| 5.1.10.1 | Metadata on Variables | 183 |
| 5.1.10.2 | Metadata on Conversion Methods | 185 |
| 5.1.10.3 | Metadata on Acquisition Rasters / Processor Tasks | 187 |
| 5.1.11 | Variable Ref and Value Representation Mode..... | 188 |
| 5.1.12 | Data Capturing..... | 190 |
| 5.1.12.1 | Introduction..... | 190 |
| 5.1.12.2 | Capture Configuration and Control | 190 |
| 5.1.12.3 | Untriggered Capturing | 196 |
| 5.1.12.4 | Triggered Capturing | 197 |
| 5.1.12.5 | Re-triggered Capturing | 199 |
| 5.1.12.6 | Obtain Capture Results from a Capture..... | 201 |
| 5.1.12.7 | Capture Result | 202 |
| 5.1.12.8 | Relation between Triggers, Capture State, Capture Events and Data Frames..... | 206 |
| 5.1.12.9 | Reader and Writer for CaptureResult..... | 215 |
| 5.1.12.10 | Usage examples for Capture and Capture Result | 216 |
| 5.2 | Model access Port | 227 |
| 5.2.1 | User Concept | 227 |
| 5.2.1.1 | General..... | 227 |
| 5.2.1.2 | MAPort Interface | 227 |
| 5.2.1.3 | States of the MAPort | 229 |
| 5.2.2 | Usage of MAPort..... | 231 |
| 5.2.2.1 | Creation and Configuration | 231 |
| 5.2.2.2 | Obtaining Information on Available Model Variables, Tasks and their Properties | 233 |
| 5.2.2.3 | Reading & Writing Model Variables | 236 |
| 5.2.2.4 | State dependency of Variables' Writeability and Readability | 240 |
| 5.2.2.5 | Relation between MAPort and Capturing / SignalGenerator | 241 |
| 5.2.2.6 | Pausing and stepwise execution of the simulation | 242 |
| 5.3 | Diagnostic Port | 246 |
| 5.3.1 | Overview | 246 |
| 5.3.2 | API..... | 247 |
| 5.3.2.1 | Communication Modes..... | 248 |
| 5.3.2.2 | ECU | 248 |
| 5.3.2.3 | Functional Groups | 249 |
| 5.3.3 | States of the DiagPort | 249 |
| 5.3.4 | Usage of this Port | 251 |
| 5.3.4.1 | Creation and Configuration | 251 |
| 5.3.4.2 | Getting The Ecu Object | 252 |
| 5.3.4.3 | Reading And Clearing The Fault Memory | 253 |
| 5.3.4.4 | Reading The Variant Coding Data | 254 |
| 5.3.4.5 | Reading Identification Data | 254 |
| 5.3.4.6 | Reading and Writing Values from and to the Eeprom by Alias Names | 255 |
| 5.3.4.7 | Reading from the Eeprom | 256 |
| 5.3.4.8 | Writing to the Eeprom..... | 256 |
| 5.3.4.9 | Implicit and Explicit Communication..... | 257 |
| 5.3.4.10 | Sending Hex Services with Explicit Communication | 257 |
| 5.3.4.11 | Executing Jobs | 258 |
| 5.3.4.12 | Reading Data from a Functional Group | 259 |
| 5.3.4.13 | Using the Basecontroller | 260 |
| 5.3.5 | Special Hints | 260 |
| 5.3.5.1 | Structure of Returned Collections | 260 |
| 5.3.5.2 | States in the Diagnostic Tool | 260 |
| 5.4 | ECUMPort | 261 |

| | | |
|------------|--|------------|
| 5.4.1 | Overview | 261 |
| 5.4.2 | States of the ECUMPort | 264 |
| 5.4.3 | Usage of ECUMPort | 266 |
| 5.4.3.1 | Creation and Configuration | 266 |
| 5.4.3.2 | Getting Lists of Variable and Task Names | 267 |
| 5.4.3.3 | Read a Scalar Variable Value and its Properties | 268 |
| 5.4.3.4 | Read an Array Variable Value and its Properties | 268 |
| 5.4.3.5 | Read a Matrix Variable Value and its Properties | 269 |
| 5.4.3.6 | Capturing ECU Variables | 270 |
| 5.5 | ECUCPort | 274 |
| 5.5.1 | Overview | 274 |
| 5.5.2 | States of the ECUCPort | 275 |
| 5.5.3 | Usage of ECUCPort | 277 |
| 5.5.3.1 | Creation and Configuration | 277 |
| 5.5.3.2 | Accessing ECU Parameters | 278 |
| 5.5.3.3 | Getting the List of Variables of the ECUCPort | 279 |
| 5.5.3.4 | Manage ECU Memory Pages | 280 |
| 5.6 | EES Port | 282 |
| 5.6.1 | User Concept | 282 |
| 5.6.1.1 | General | 282 |
| 5.6.1.2 | Configuration and Execution of Electrical Errors | 284 |
| 5.6.1.3 | Triggers in EES | 286 |
| 5.6.1.4 | Electrical Errors | 286 |
| 5.6.1.5 | API | 289 |
| 5.6.1.6 | States of the EES Port | 295 |
| 5.6.2 | Usage of this Port | 298 |
| 5.6.2.1 | Port Creation and Configuration | 298 |
| 5.6.2.2 | Creating Error Configurations | 299 |
| 5.6.2.3 | Error Stimulation | 302 |
| 5.6.2.4 | Extension of Error Stimulation | 302 |
| 5.6.2.5 | Creating Error Objects | 304 |
| 5.6.2.6 | Loading Error Configurations from File | 308 |
| 5.6.3 | Special Hints | 309 |
| 5.6.3.1 | EES Hardware Limitations and Extensions | 309 |
| 5.7 | Network Port | 310 |
| 5.7.1 | User Concept | 310 |
| 5.7.1.1 | General | 310 |
| 5.7.1.2 | Network Port | 311 |
| 5.7.1.3 | States of the Network Port | 312 |
| 5.7.2 | Usage of the Network Port | 314 |
| 5.7.2.1 | Port Creation and Configuration | 314 |
| 5.7.2.2 | Object Model | 315 |
| 5.7.2.3 | Mapping to DBC and FIBEX | 317 |
| 5.7.2.4 | Navigating the Object Model | 318 |
| 5.7.2.5 | Send and Receive Frames | 319 |
| 5.7.2.6 | Send and Receive Signals | 322 |
| 5.7.2.7 | Capturing of Bus Signals | 324 |
| 5.7.2.8 | Capturing of Bus Frames | 327 |
| 5.7.2.9 | Replay of Bus Frames | 330 |
| 5.7.2.10 | Extending the CAN object model | 331 |
| 6 | Symbols and Abbreviated Terms | 334 |
| 7 | Bibliography | 335 |