ASAM

Association for Standardization of
Automation and Measuring Systems

ASAM OTX Extensions

Open Test eXchange Format

Part 4 of 4

Interface Definition

Version 3.0.0

Date: 2020-01-31

Base Standard

© by ASAM e.V., 2020

Disclaimer

This document is the copyrighted property of ASAM e.V.
Any use is limited to the scope described in the license terms. The license terms can be viewed at www.asam.net/license

Table of Contents

Foreword 30

1 Introduction 31

1.1 Overview 31

1.2 Scope 32

2 Extension overview 34

2.1 General 34

2.2 Dependencies 34

3 Requirements listing 39

3.1 Assertion Requirements 39
3.1.1 A01 – Add assertions to OTX procedures to verify correctness 39

3.2 BlackBox Requirements 39
3.2.1 BB01 – Transport unknown data types 39

3.3 BusMonitoring Requirements 39
3.3.1 BM01 – Bus monitoring 39
3.3.2 BM02 – Bus tracing 39

3.4 ComInterface Requirements 39
3.4.1 CI01 – Get communication interfaces and their resources at runtime and use them. 39
3.4.2 CI02 – Using of communication interfaces methods. 40
3.4.3 CI03 – Activate and deactivate Ethernet 40

3.5 CommonDialogs Requirements 40
3.5.1 CD01 – It shall be possible to select a file system resource for the purposes of loading or saving file(s). 40

3.6 DataType Requirements 40
3.6.1 DT01 – Efficient access to named collections (Enumeration) 40
3.6.2 DT02 – Support of Structures 40

3.7 DiagComPlus Requirements 41
3.7.1 DCP01 – Creating `diag:ComChannel` without starting communication 41
3.7.2 DCP02 – Getting the state of an initialized `diag:ComChannel` 41
3.7.3 DCP03 – Getting all ComParameters as `otx:List` 41
3.7.4 DCP04 – Executing a functional hex service and get responses of each ECU that responed 41
3.7.5 DCP05 – Start and stop communication 41

3.8 DiagConfiguration Requirements 41
3.8.1 DC01 – Selecting the diagnostic project that contains the diagnostic data base 41
3.8.2 DC02 – Selecting the vehicle information that contains the settings of the diagnostic data base 42

3.9 DiagDataBrowsingPlus Requirements 42

3.9.1 DDBP01 – Reading static information for MCDDbParameter 42
3.9.2 DDBP02 – Reading static information for MCDDbTable 42
3.9.3 DDBP03 – Reading static information for MCDDbEnvDataDesc 42
3.9.4 DDBP04 – Reading static information for MCDDbDiagTroubleCode 42
3.9.5 DDBP05 – Reading static information for MCDDbFaultMemory 42
3.9.6 DDBP06 – Reading static information for MCDDbMatchingParameter . 43
3.9.7 DDBP07 – Reading static information for MCDDbSpecialDataElement 43
3.9.8 DDBP08 – Reading static information for MCDDbSpecialDataGroup ... 43
3.9.9 DDBP09 – Reading static information for MCDDbTextTableElement ... 43
3.9.10 DDBP10 – Reading static information for MCDInterval 43
3.9.11 DDBP11 – Reading static information for MCDDbSubComponent 43

3.10 ECUConfiguration Requirements 44
3.10.1 EC01 – Configuration of an ECU by using a data base (ODX-E file). ... 44

3.11 EventPlus Requirements 44
3.11.1 EP01 – Monitor changes on variables of complex types 44

3.12 ExternalServiceProvider Requirements 44
3.12.1 ESP01 – Add method calls of encapsulated libraries into OTX test sequences. 44
3.12.2 ESP02 – Add a proprietary test sequence into an OTX test sequence. 44
3.12.3 ESP03 – Add any external functionality to an OTX test sequence..... 44

3.13 File Requirements 45
3.13.1 F01 – Read and write textual files 45
3.13.2 F02 – Read and write binary files 45

3.14 FlashPlus Requirements 45
3.14.1 FP01 – Enable latebound flashing (select binary file while execution of a test). 45

3.15 Persistence Requirements 45
3.15.1 P01 – It shall be possible to save and load the value of all SimpleTypes and ByteField using persistent storage. 45
3.15.2 P02 – It shall be possible to save and load Collection types (List and Map) using persistent storage if the contents of the collections can also be persisted. 45
3.15.3 P03 – OTX Extensions may define additional data types that can be persisted. 45

3.16 SQL Requirements 46
3.16.1 SQL01 – Establishing database connections 46
3.16.2 SQL02 – Executing of database commands..... 46
3.16.3 SQL03 – Retrieving results of a database command..... 46
3.16.4 SQL04 – Retrieving results shall be possible synchronously and asynchronously 46

3.17 StateMachineProcedure Requirements 46
3.17.1 SMP01 – Description of state based workflows..... 46

3.18 StateVariable Requirements 46
3.18.1 SV01 – Support for state variables, which are the counterpart of context variables 46

3.19 TestResultHandling Requirements 47
3.19.1 RH01 – Capturing of test result data 47
3.19.2 RH02 – Evaluation of test result data 47
3.19.3 RH03 – Summarizing of test results in groups..... 47

3.19.4 RH04 – Defining different test result levels 47
3.19.5 RH05 – Multiple test instances 47
3.20 Util Requirements 47
3.20.1 U01 – Copying `otx:ByteFields` 47
3.20.2 U02 – Comparing values of complex types 48
3.20.3 U03 – Getting a random number 48
3.20.4 U04 – Checking a variables´ status 48
3.20.5 U05 – Simplify analyzing the content of a list 48
3.20.6 U06 – More possibilities to format a string 48
3.21 VehicleInfo Requirements 48
3.21.1 VI01 – Getting the gateway mode of an ECU 48
3.21.2 VI02 – Getting names of gateways that accesses an ECU 48
3.21.3 VI03 – Checking if ECU is accessed via gateways 49
3.22 XML Requirements 49
3.22.1 X01 – The User shall be able to set XML Processing Instructions 49
3.22.2 X02 – The User shall be able to edit attributes, nodes and node text values. 49
3.22.3 X03 – The User shall be able to add comments to a XML Document. 49
3.22.4 X04 – The User shall be able to remove attributes and nodes. 49
3.22.5 X05 – Validation of an xml document 49
3.22.6 X06 – The User shall be able to define the document encoding and version 49
3.22.7 X07 – The User shall be able to parse XML content from file or ByteField 50
3.22.8 X08 – The User shall be able to query XML Elements by XPath 50
3.23 ZipHandling Requirements 50
3.23.1 Z01 – Functionality shall be provided to extract a Zip file 50
3.23.2 Z02 – Filter functionality for the file compress and decompress process shall be provided 50
3.23.3 Z03 – The User shall decide whether existing Files should be overwritten by the decompress process. 50
3.23.4 Z04 – The User shall decide whether the target Zip file should be overwritten by the compress process. 51
3.23.5 Z05 – The Zip File shall be a URI. 51
4 OTX Assertion Extension 52
4.1 Introduction 52
4.2 Exceptions 52
4.2.1 Overview 52
4.2.2 Syntax 52
4.2.3 Semantics 53
4.2.3.1 General 53
4.2.3.2 AssertionException 53
4.3 Actions 53
4.3.1 Overview 53
4.3.2 Syntax 53
4.3.3 General Semantics 54
4.3.3.1 Assert 54
5 OTX BlackBox Extension 56

5.1 Introduction 56
5.2 Datatypes 56
5.2.1 Overview 56
5.2.2 Syntax 56
5.2.3 Semantics 57
5.2.3.1 BlackBox 57
5.3 Variable access 57
5.3.1 Overview 57
5.3.2 Syntax 57
5.3.3 Semantics 58
5.4 Terms 58
5.4.1 Overview 58
5.4.2 Syntax 58
5.4.3 General Semantics 59
5.4.3.1 BlackBoxTerm 59
5.4.3.2 BlackBoxValue 59
6 OTX BusMonitoring Extension 61
6.1 Introduction 61
6.2 Datatypes 61
6.2.1 Overview 61
6.2.2 Syntax 61
6.2.3 Semantics 62
6.2.3.1 BusFrame 62
6.2.3.2 BusMonitor 62
6.2.3.3 BusMonitorMode 63
6.3 Enumerations 63
6.3.1 Overview 63
6.3.2 Syntax 63
6.3.3 Semantics 64
6.3.3.1 BusMonitorModes 64
6.4 Exceptions 64
6.4.1 Overview 64
6.4.2 Syntax 64
6.4.3 Semantics 65
6.4.3.1 General 65
6.4.3.2 BusMonitoringException 65
6.4.3.3 NotSupportedException 66
6.5 Variable access 66
6.5.1 Overview 66
6.5.2 Syntax 66
6.5.3 Semantics 67
6.6 Actions 67
6.6.1 Overview 67
6.6.2 Syntax 67
6.6.3 General Semantics 68
6.6.3.1 StartBusMonitoring 68
6.6.3.2 StopBusMonitoring 69
6.7 Terms 69

6.7.1 Overview ... 69
6.7.2 Syntax ... 69
6.7.3 General Semantics ... 70
6.7.3.1 BusFrameTerm ... 70
6.7.3.2 BusFrameValue ... 70
6.7.3.3 BusMonitorEventSource ... 71
6.7.3.4 BusMonitorModeLiteral ... 71
6.7.3.5 BusMonitorModeTerm ... 72
6.7.3.6 BusMonitorModeValue ... 72
6.7.3.7 BusMonitorTerm ... 72
6.7.3.8 BusMonitorValue ... 72
6.7.3.9 FetchBusMonitorBusFrames ... 73
6.7.3.10 GetBusFrameAddress ... 73
6.7.3.11 GetBusFrameAsString ... 74
6.7.3.12 GetBusFrameData ... 74
6.7.3.13 GetBusFrameTimestamp ... 75
6.7.3.14 GetBusFrameType ... 75
6.7.3.15 IsBusMonitorEvent ... 76

7 OTX ComInterface Extension 77

7.1 Introduction ... 77

7.2 Datatypes ... 77
7.2.1 Overview ... 77
7.2.2 Syntax ... 77
7.2.3 Semantics ... 78
7.2.3.1 ComInterface ... 78
7.2.3.2 ConnectionStatus ... 78

7.3 Enumerations ... 79
7.3.1 Overview ... 79
7.3.2 Syntax ... 79
7.3.3 Semantics ... 79
7.3.3.1 ConnectionStates ... 79

7.4 Exceptions ... 80
7.4.1 Overview ... 80
7.4.2 Syntax ... 80
7.4.3 Semantics ... 81
7.4.3.1 General ... 81
7.4.3.2 ActivateEthernetException ... 81
7.4.3.3 ComInterfaceException ... 81
7.4.3.4 IgnitionStateException ... 81
7.4.3.5 NoDefaultComInterfaceException ... 81
7.4.3.6 NotConnectedException ... 81

7.5 Variable access ... 81
7.5.1 Overview ... 81
7.5.2 Syntax ... 81
7.5.3 Semantics ... 82

7.6 Actions ... 82
7.6.1 Overview ... 82
7.6.2 Syntax ... 82
7.6.3 General Semantics ... 83
7.6.3.1 ActivateEthernet ... 83

7.6.3.2 CloseComInterface ... 84
7.6.3.3 ConnectComInterface ... 84
7.6.3.4 DeactivateEthernet ... 85

7.7 Terms ... 85
7.7.1 Overview ... 85
7.7.2 Syntax ... 85
7.7.3 Semantics for ComInterface Terms ... 86
7.7.3.1 ComInterfaceTerm ... 86
7.7.3.2 ComInterfaceValue ... 86
7.7.3.3 CreateComChannelFromComInterface ... 87
7.7.3.4 GetBatteryVoltageFromComInterface ... 88
7.7.3.5 GetComChannelFromComInterface ... 89
7.7.3.6 GetComInterface ... 91
7.7.3.7 GetComInterfaceNameListFromEthernet ... 92
7.7.3.8 GetComInterfaceProperties ... 93
7.7.3.9 GetComInterfaceResourceNameList ... 94
7.7.3.10 GetIgnitionStateFromComInterface ... 94
7.7.3.11 IsEthernetActivated ... 95
7.7.3.12 IsInterfaceConnected ... 95
7.7.4 Semantics for Enumeration Terms ... 95
7.7.4.1 ConnectionStatusLiteral ... 95
7.7.4.2 ConnectionStatusTerm ... 96
7.7.4.3 ConnectionStatusValue ... 96
7.7.5 General Semantics ... 96
7.7.5.1 GetComInterfaceNameList ... 96
7.7.5.2 GetDefaultComInterfaceName ... 97

8 OTX CommonDialogs Extension 98

8.1 Introduction ... 98

8.2 Exceptions ... 98
8.2.1 Overview ... 98
8.2.2 Syntax ... 98
8.2.3 Semantics ... 99
8.2.3.1 General ... 99
8.2.3.2 CommonDialogsException ... 99

8.3 Actions ... 99
8.3.1 Overview ... 99
8.3.2 Syntax ... 99
8.3.3 General Semantics ... 100
8.3.3.1 FileOpenDialog ... 100
8.3.3.2 FileSaveDialog ... 101
8.3.3.3 SelectDirectoryDialog ... 102

9 OTX DataType Extension 104

9.1 Introduction ... 104

9.2 Datatypes ... 104
9.2.1 Overview ... 104
9.2.2 Syntax ... 104
9.2.3 Semantics ... 105
9.2.3.1 Enumeration ... 105

9.2.3.2 ResourceLocation ... 106
9.2.3.3 Structure ... 106
9.3 Exceptions ... 107
9.3.1 Overview ... 107
9.3.2 Syntax ... 107
9.3.3 Semantics ... 108
9.3.3.1 General ... 108
9.3.3.2 DataTypeException ... 108
9.4 Variable access ... 108
9.4.1 Overview ... 108
9.4.2 Syntax ... 108
9.4.3 Semantics ... 109
9.5 Declaration and Arguments ... 109
9.5.1 Syntax ... 109
9.5.2 Semantics ... 110
9.6 Signatures ... 110
9.6.1 Overview ... 110
9.6.2 Syntax ... 110
9.6.3 Semantics for Enumerations ... 111
9.6.3.1 EnumerationSignature ... 111
9.6.4 Semantics for Structures ... 112
9.6.4.1 StructureSignature ... 112
9.7 Terms ... 113
9.7.1 Overview ... 113
9.7.2 Syntax ... 113
9.7.3 Semantics for EnumerationTerms ... 115
9.7.3.1 EnumerationContainsName ... 115
9.7.3.2 EnumerationContainsValue ... 115
9.7.3.3 EnumerationGetEntryList ... 115
9.7.3.4 EnumerationLiteral ... 116
9.7.3.5 EnumerationTerm ... 116
9.7.3.6 EnumerationValue ... 117
9.7.3.7 GetEnumerationByName ... 117
9.7.3.8 GetEnumerationByValue ... 117
9.7.4 Semantics for RessourceLocationTerms ... 118
9.7.4.1 CreateResourceLocation ... 118
9.7.4.2 GetResourceLocationId ... 118
9.7.4.3 IsResourceLocationMapped ... 119
9.7.4.4 ResourceLocationLiteral ... 119
9.7.4.5 ResourceLocationTerm ... 120
9.7.4.6 ResourceLocationValue ... 120
9.7.5 Semantics for StructureTerms ... 120
9.7.5.1 StructureCopy ... 120
9.7.5.2 StructureCreate ... 121
9.7.5.3 StructureTerm ... 121
9.7.5.4 StructureValue ... 121
10 OTX DiagComPlus Extension 123
10.1 Introduction ... 123
10.2 Datatypes ... 123

10.2.1 Overview ... 123
10.2.2 Syntax ... 123
10.2.3 Semantics ... 124
10.2.3.1 ComChannelState ... 124
10.3 Enumerations ... 125
10.3.1 Overview ... 125
10.3.2 Syntax ... 125
10.3.3 Semantics ... 125
10.3.3.1 ComChannelStates ... 125
10.4 Exceptions ... 126
10.4.1 Overview ... 126
10.4.2 Syntax ... 126
10.4.3 Semantics ... 127
10.4.3.1 General ... 127
10.4.3.2 DiagComPlusException ... 127
10.5 Variable access ... 127
10.5.1 Overview ... 127
10.5.2 Syntax ... 127
10.5.3 Semantics ... 128
10.6 Actions ... 128
10.6.1 Overview ... 128
10.6.2 Syntax ... 128
10.6.3 General Semantics ... 129
10.6.3.1 ExecuteHexDiagServiceFunctional ... 129
10.6.3.2 StartCommunication ... 130
10.6.3.3 StopCommunication ... 130
10.7 Terms ... 131
10.7.1 Overview ... 131
10.7.2 Syntax ... 131
10.7.3 General Semantics ... 132
10.7.3.1 ComChannelStateLiteral ... 132
10.7.3.2 ComChannelStateTerm ... 132
10.7.3.3 ComChannelStateValue ... 133
10.7.3.4 CreateComChannel ... 133
10.7.3.5 GetComChannelState ... 134
10.7.3.6 GetComParameterList ... 135
11 OTX DiagConfiguration Extension 136
11.1 Introduction ... 136
11.2 Exceptions ... 136
11.2.1 Overview ... 136
11.2.2 Syntax ... 136
11.2.3 Semantics ... 137
11.2.3.1 General ... 137
11.2.3.2 ProjectChangeException ... 137
11.2.3.3 DiagConfigurationException ... 137
11.3 Actions ... 138
11.3.1 Overview ... 138
11.3.2 Syntax ... 138
11.3.3 General Semantics ... 138

11.3.3.1 SelectProject ... 138
11.3.3.2 SelectVehicleInformation ... 139

11.4 Terms ... 140
11.4.1 Overview ... 140
11.4.2 Syntax ... 140
11.4.3 General Semantics ... 140
11.4.3.1 GetActiveProject ... 140
11.4.3.2 GetActiveProjectVersion ... 141
11.4.3.3 GetActiveVehicleInformation ... 141
11.4.3.4 GetDbProjectList ... 142
11.4.3.5 GetDbVehicleInformationList ... 142

12 OTX DiagDataBrowsingPlus Extension 143

12.1 Introduction ... 143

12.2 Datatypes ... 143
12.2.1 Overview ... 143
12.2.2 Syntax ... 143
12.2.3 Semantics ... 144
12.2.3.1 DbComChannel ... 144
12.2.3.2 DbDiagService ... 144
12.2.3.3 DbDiagTroubleCode ... 144
12.2.3.4 DbEnvDataDesc ... 145
12.2.3.5 DbFaultMemory ... 145
12.2.3.6 DbMatchingParameter ... 145
12.2.3.7 DbObject ... 145
12.2.3.8 DbParameter ... 145
12.2.3.9 DbRequest ... 145
12.2.3.10 DbResponse ... 145
12.2.3.11 DbSpecialDataElement ... 146
12.2.3.12 DbSpecialDataGroup ... 146
12.2.3.13 DbSubComponent ... 146
12.2.3.14 DbTable ... 146
12.2.3.15 Interval ... 146
12.2.3.16 McdDataType ... 147
12.2.3.17 McdParameterType ... 147
12.2.3.18 McdResponseType ... 147
12.2.3.19 TextTableElement ... 148

12.3 Enumerations ... 148
12.3.1 Overview ... 148
12.3.2 Syntax ... 148
12.3.3 Semantics ... 149
12.3.3.1 McdDataTypes ... 149
12.3.3.2 McdParameterTypes ... 151
12.3.3.3 McdResponseTypes ... 151

12.4 Exceptions ... 152
12.4.1 Overview ... 152
12.4.2 Syntax ... 152
12.4.3 Semantics ... 152
12.4.3.1 General ... 152
12.4.3.2 DiagDataBrowsingPlusException ... 153
12.4.3.3 InvalidTypeException ... 153

12.4.3.4 NotSupportedException 153
12.5 Variable access 153
12.5.1 Overview 153
12.5.2 Syntax 153
12.5.3 Semantics 154
12.6 Terms 154
12.6.1 Overview 154
12.6.2 Semantics for DbComChannel Terms 154
12.6.2.1 DbComChannelTerm 155
12.6.2.2 DbComChannelValue 155
12.6.2.3 GetComChannelDbComChannel 155
12.6.2.4 GetDbComChannel 156
12.6.2.5 GetDbComChannelProtocolType 157
12.6.3 Semantics for DbDiagService Terms 157
12.6.3.1 DbDiagServiceTerm 158
12.6.3.2 DbDiagServiceValue 158
12.6.3.3 GetDbComChannelDbDiagServices 159
12.6.3.4 GetDbDiagServiceAudienceStates 159
12.6.3.5 GetDbDiagServiceDbFunctionalClasses 160
12.6.3.6 GetDbDiagServiceDbPreConditionStatesBySemantic 160
12.6.3.7 GetDbDiagServiceDisabledAdditionalAudiences 161
12.6.3.8 GetDbDiagServiceEnabledAdditionalAudiences 161
12.6.3.9 GetDbDiagServiceIsApiExecutable 162
12.6.3.10 GetDbDiagServiceSemantic 162
12.6.3.11 GetDiagServiceDbDiagService 163
12.6.3.12 IsDbDiagServiceJob 163
12.6.3.13 IsDbDiagServiceRepetitive 164
12.6.4 Semantics for DbDiagTroubleCode Terms 164
12.6.4.1 DbDiagTroubleCodeTerm 165
12.6.4.2 DbDiagTroubleCodeValue 165
12.6.4.3 GetDbDiagTroubleCodeDisplayTroubleCode 166
12.6.4.4 GetDbDiagTroubleCodeDTCText 166
12.6.4.5 GetDbDiagTroubleCodeLevel 166
12.6.4.6 GetDbDiagTroubleCodeSpecialDataGroups 167
12.6.4.7 GetDbDiagTroubleCodeTextId 167
12.6.4.8 GetDbDiagTroubleCodeTroubleCode 168
12.6.4.9 GetParameterDbDiagTroubleCode 168
12.6.5 Semantics for DbEcuVariant Terms 169
12.6.5.1 GetDbEcuVariantList 169
12.6.6 Semantics for DbEnvDataDesc Terms 170
12.6.6.1 DbEnvDataDescTerm 170
12.6.6.2 DbEnvDataDescValue 170
12.6.6.3 GetDbComChannelDbEnvDataDescs 171
12.6.6.4 GetDbEnvDataDescCommonDbEnvDatas 171
12.6.6.5 GetDbEnvDataDescSpecificDbEnvDatas 172
12.6.7 Semantics for DbFaultMemory Terms 172
12.6.7.1 DbFaultMemoryTerm 172
12.6.7.2 DbFaultMemoryValue 173
12.6.7.3 GetDbComChannelDbFaultMemories 173
12.6.7.4 GetDbFaultMemoryDiagTroubleCodeByTroubleCode 173
12.6.7.5 GetDbFaultMemoryDiagTroubleCodes 174
12.6.8 Semantics for DbMatchingParameter Terms 174
12.6.8.1 DbMatchingParameterTerm 175

12.6.8.2 DbMatchingParameterValue 175
12.6.8.3 GetDbMatchingParameterExpectedValueAsString 175
12.6.9 Semantics for DbObject Terms 176
12.6.9.1 DbObjectTerm 176
12.6.9.2 DbObjectValue 177
12.6.9.3 GetDbObjectDescription 177
12.6.9.4 GetDbObjectDescriptionID 177
12.6.9.5 GetDbObjectLongName 178
12.6.9.6 GetDbObjectLongNameID 178
12.6.9.7 GetDbObjectShortName 179
12.6.9.8 GetDbObjectTypeAsString 179
12.6.9.9 GetDbObjectUniqueObjectIdentifier 180
12.6.10 Semantics for DbParameter Terms 180
12.6.10.1 DbParameterTerm 182
12.6.10.2 DbParameterValue 182
12.6.10.3 GetDbParameterAudienceStates 182
12.6.10.4 GetDbParameterBitLength 183
12.6.10.5 GetDbParameterBitPos 183
12.6.10.6 GetDbParameterByteLength 183
12.6.10.7 GetDbParameterCodedDefaultValueAsString 184
12.6.10.8 GetDbParameterDataType 184
12.6.10.9 GetDbParameterDecimalPlaces 185
12.6.10.10 GetDbParameterDefaultValueAsString 185
12.6.10.11 GetDbParameterDisabledAdditionalAudiences 186
12.6.10.12 GetDbParameterDisplayLevel 186
12.6.10.13 GetDbParameterDisplayUnitAsString 187
12.6.10.14 GetDbParameterEnabledAdditionalAudiences 187
12.6.10.15 GetDbParameterKeysAsString 188
12.6.10.16 GetDbParameterLengthKey 188
12.6.10.17 GetDbParameterMaxLength 189
12.6.10.18 GetDbParameterMaxNumberOfItems 189
12.6.10.19 GetDbParameterMinLength 190
12.6.10.20 GetDbParameterNrcConstValues 190
12.6.10.21 GetDbParameterODXBytePos 191
12.6.10.22 GetDbParameterRadix 191
12.6.10.23 GetDbParameters 192
12.6.10.24 GetDbParameterSemantic 192
12.6.10.25 GetDbParameterSpecialDataGroups 192
12.6.10.26 GetDbParameterStructureByKey 193
12.6.10.27 GetDbParameterTable 193
12.6.10.28 GetDbParameterTableKeyParam 194
12.6.10.29 GetDbParameterTableStructParams 194
12.6.10.30 GetParameterDbParameter 195
12.6.10.31 IsDbParameterConstant 195
12.6.10.32 IsDbParameterVariableLength 196
12.6.11 Semantics for DbRequest Terms 196
12.6.11.1 DbRequestTerm 197
12.6.11.2 DbRequestValue 197
12.6.11.3 GetDbDiagServiceDbRequest 198
12.6.11.4 GetDbRequestDbParameters 198
12.6.11.5 GetDbRequestDefaultPDU 199
12.6.11.6 GetDbRequestPDUMaxLength 199
12.6.11.7 GetDbRequestPDUMinLength 199
12.6.11.8 GetRequestDbRequest 200

12.6.12 Semantics for DbResponse Terms 200
12.6.12.1 DbResponseTerm 201
12.6.12.2 DbResponseValue 201
12.6.12.3 GetDbDiagServiceDbResponses 202
12.6.12.4 GetDbMatchingParameterDbResponseParameter 202
12.6.12.5 GetDbResponseDbParameters 203
12.6.12.6 GetDbResponseResponseType 203
12.6.12.7 GetResponseDbResponse 203
12.6.13 Semantics for DbSpecialDataElement Terms 204
12.6.13.1 DbSpecialDataElementTerm 204
12.6.13.2 DbSpecialDataElementValue 205
12.6.13.3 GetDbSpecialDataElementContent 205
12.6.13.4 GetDbSpecialDataElementSemanticInformation 205
12.6.13.5 GetDbSpecialDataElementTextId 206
12.6.14 Semantics for DbSpecialDataGroup Terms 206
12.6.14.1 DbSpecialDataGroupTerm 207
12.6.14.2 DbSpecialDataGroupValue 207
12.6.14.3 GetDbDiagServiceDbSpecialDataGroups 208
12.6.14.4 GetDbRequestDbSpecialDataGroups 208
12.6.14.5 GetDbResponseDbSpecialDataGroups 209
12.6.14.6 GetDbSpecialDataGroupCaption 209
12.6.14.7 GetDbSpecialDataGroupHasCaption 209
12.6.14.8 GetDbSpecialDataGroupSemanticInformation 210
12.6.14.9 GetDbSpecialDataGroupSpecialDataElements 210
12.6.14.10 GetDbSpecialDataGroupSpecialDataGroups 211
12.6.15 Semantics for DbSubComponent Terms 211
12.6.15.1 DbSubComponentTerm 212
12.6.15.2 DbSubComponentValue 212
12.6.15.3 GetDbComChannelDbSubComponents 213
12.6.15.4 GetDbSubComponentDbDiagServices 213
12.6.15.5 GetDbSubComponentDbDiagTroubleCodes 214
12.6.15.6 GetDbSubComponentDbEnvDataDescs 214
12.6.15.7 GetDbSubComponentDbFaultMemories 215
12.6.15.8 GetDbSubComponentDbInParams 215
12.6.15.9 GetDbSubComponentDbMatchingParameters 216
12.6.15.10 GetDbSubComponentDbOutParams 216
12.6.15.11 GetDbSubComponentDbResponseParameters 216
12.6.15.12 GetDbSubComponentSemantic 217
12.6.16 Semantics for DbTable Terms 217
12.6.16.1 DbTableTerm 218
12.6.16.2 DbTableValue 218
12.6.16.3 GetDbComChannelDbTables 219
12.6.16.4 GetDbSubComponentDbTableParameters 219
12.6.16.5 GetDbSubComponentDbTables 220
12.6.16.6 GetDbTableDbTableRows 220
12.6.16.7 GetDbTableDiagComPrimitiveByConnectorSemantic 221
12.6.16.8 GetDbTableDiagComPrimitives 221
12.6.16.9 GetDbTableKeys 222
12.6.16.10 GetDbTableParameterKeyAsString 222
12.6.16.11 GetDbTableSemantic 223
12.6.16.12 GetDbTableSpecialDataGroups 223
12.6.17 Semantics for Interval Terms 224
12.6.17.1 GetDbParameterValidInternalIntervals 224
12.6.17.2 GetDbParameterValidPhysicalIntervals 224

12.6.17.3 GetIntervalLowerLimitAsString ... 225
12.6.17.4 GetIntervalLowerLimitTypeAsString ... 225
12.6.17.5 GetIntervalUpperLimitAsString ... 226
12.6.17.6 GetIntervalUpperLimitTypeAsString ... 226
12.6.17.7 IntervalTerm ... 226
12.6.17.8 IntervalValue ... 227
12.6.18 Semantics for McdDataType Terms ... 227
12.6.18.1 McdDataTypeLiteral ... 227
12.6.18.2 McdDataTypeTerm ... 228
12.6.18.3 McdDataTypeValue ... 228
12.6.19 Semantics for McdParameter Terms ... 228
12.6.19.1 GetDbParameterMcdParameterType ... 229
12.6.19.2 McdParameterTypeLiteral ... 229
12.6.19.3 McdParameterTypeTerm ... 230
12.6.19.4 McdParameterTypeValue ... 230
12.6.20 Semantics for McdResponseType Terms ... 230
12.6.20.1 McdResponseTypeLiteral ... 231
12.6.20.2 McdResponseTypeTerm ... 231
12.6.20.3 McdResponseTypeValue ... 231
12.6.21 Semantics for Parameter Terms ... 232
12.6.21.1 GetParameterDecimalPlaces ... 232
12.6.21.2 GetParameterDisplayUnitAsString ... 233
12.6.21.3 GetParameterRadix ... 233
12.6.21.4 IsFloatParameter ... 234
12.6.21.5 IsIntegerParameter ... 235
12.6.21.6 IsParameterConstant ... 235
12.6.21.7 IsTextTableParameter ... 236
12.6.22 Semantics for TextTableElement Terms ... 236
12.6.22.1 GetDbParameterTextTableElements ... 237
12.6.22.2 GetTextTableElementInterval ... 237
12.6.22.3 GetTextTableElementLongName ... 238
12.6.22.4 GetTextTableElementLongNameID ... 238
12.6.22.5 TextTableElementTerm ... 239
12.6.22.6 TextTableElementValue ... 239

13 OTX EcuConfiguration Extension 240

13.1 Introduction ... 240

13.2 Datatypes ... 240
13.2.1 Overview ... 240
13.2.2 Syntax ... 240
13.2.3 Semantics ... 241
13.2.3.1 DbConfigurationData ... 241
13.2.3.2 DbConfigurationRecord ... 241
13.2.3.3 DbDataRecord ... 241
13.2.3.4 DbItemValue ... 241
13.2.3.5 DbOptionItem ... 241

13.3 Exceptions ... 242
13.3.1 Overview ... 242
13.3.2 Syntax ... 242
13.3.3 Semantics ... 242
13.3.3.1 General ... 242
13.3.3.2 EcuConfigurationException ... 242

13.4 Variable access 243
13.4.1 Overview 243
13.4.2 Syntax 243
13.4.3 Semantics 244
13.5 Terms 245
13.5.1 Overview 245
13.5.2 Semantics for DbConfigurationData Terms 245
13.5.2.1 DbConfigurationDataTerm 245
13.5.2.2 DbConfigurationDataValue 245
13.5.2.3 GetDbComChannelDbConfigurationDatas 246
13.5.3 Semantics for DbConfigurationRecord Terms 246
13.5.3.1 DbConfigurationRecordTerm 247
13.5.3.2 DbConfigurationRecordValue 247
13.5.3.3 GetDbConfigurationDataDbConfigurationRecords 248
13.5.4 Semantics for DbDataRecord Terms 248
13.5.4.1 DbDataRecordTerm 249
13.5.4.2 DbDataRecordValue 250
13.5.4.3 GetDbConfigurationRecordDbDataRecordByDataId 250
13.5.4.4 GetDbConfigurationRecordDbDataRecordByKey 251
13.5.4.5 GetDbConfigurationRecordDbDataRecordByName 251
13.5.4.6 GetDbConfigurationRecordDbDataRecordDataIDs 252
13.5.4.7 GetDbConfigurationRecordDbDataRecordKeys 252
13.5.4.8 GetDbConfigurationRecordDbDataRecordNames 253
13.5.4.9 GetReadConfigurationServices 253
13.5.4.10 GetWriteConfigurationServices 254
13.5.5 Semantics for DbItemValue Terms 255
13.5.5.1 DbItemValueTerm 255
13.5.5.2 DbItemValueValue 256
13.5.5.3 GetDbItemValueKey 256
13.5.5.4 GetDbItemValueMeaning 257
13.5.5.5 GetDbItemValueMeaningID 257
13.5.5.6 GetDbItemValuePhysicalConstantValueAsString 257
13.5.5.7 GetDbItemValueRule 258
13.5.6 Semantics for DbOptionItem Terms 258
13.5.6.1 DbOptionItemTerm 260
13.5.6.2 DbOptionItemValue 260
13.5.6.3 GetDbConfigurationRecordDbOptionItems 260
13.5.6.4 GetDbOptionItemBitLength 261
13.5.6.5 GetDbOptionItemBitPosition 261
13.5.6.6 GetDbOptionItemBytePosition 262
13.5.6.7 GetDbOptionItemDataType 262
13.5.6.8 GetDbOptionItemDbItemValues 263
13.5.6.9 GetDbOptionItemDecimalPlaces 263
13.5.6.10 GetDbOptionItemInterval 263
13.5.6.11 GetDbOptionItemPhysicalDefaultValueAsString 264
13.5.6.12 GetDbOptionItemReadAudienceState 264
13.5.6.13 GetDbOptionItemSemantic 265
13.5.6.14 GetDbOptionItemTextTableElements 265
13.5.6.15 GetDbOptionItemUnitAsString 266
13.5.6.16 GetDbOptionItemWriteAudienceState 266
13.5.6.17 IsComplexDbOptionItem 266

14 OTX EventPlus Extension 268

14.1 Introduction 268
14.2 Exceptions 268
14.2.1 Overview 268
14.2.2 Syntax 268
14.2.3 Semantics 269
14.2.3.1 General 269
14.2.3.2 EventPlusException 269
14.3 Terms 269
14.3.1 Overview 269
14.3.2 Syntax 269
14.3.3 General Semantics 270
14.3.3.1 DeepMonitorChangeEventSource 270
14.3.3.2 IsDeepMonitorChangeEvent 271

15 OTX ExternalServiceProvider Extension 272
15.1 Introduction 272
15.2 Datatypes 272
15.2.1 Overview 272
15.2.2 Syntax 272
15.2.3 Semantics 273
15.2.3.1 PropertyFlag 273
15.2.3.2 Service 274
15.2.3.3 ServiceProvider 274
15.3 Enumerations 274
15.3.1 Overview 274
15.3.2 Syntax 274
15.3.3 Semantics 275
15.3.3.1 PropertyFlags 275
15.4 Exceptions 275
15.4.1 Overview 275
15.4.2 Syntax 275
15.4.3 Semantics 276
15.4.3.1 General 276
15.4.3.2 ConfigurationException 276
15.4.3.3 ExecuteException 276
15.4.3.4 ExternalServiceProviderException 277
15.4.3.5 ProviderDisposedException 277
15.4.3.6 ProviderServiceException 277
15.5 Variable access 277
15.5.1 Overview 277
15.5.2 Syntax 277
15.5.3 Semantics 278
15.6 Declaration and Arguments 278
15.6.1 Syntax 278
15.6.2 Semantics 279
15.7 Signatures 280
15.7.1 Overview 280
15.7.2 Syntax 280
15.7.3 General Semantics 281

15.7.3.1 ConstructorSignature ... 281
15.7.3.2 EventSignature ... 282
15.7.3.3 PopertyDeclaration ... 283
15.7.3.4 PropertyDeclarations ... 283
15.7.3.5 ServiceProviderSignature ... 284
15.7.3.6 ServiceSignature ... 285

15.8 Actions ... 287
15.8.1 Overview ... 287
15.8.2 Syntax ... 287
15.8.3 General Semantics ... 289
15.8.3.1 CreateProvider ... 289
15.8.3.2 DisposeProvider ... 290
15.8.3.3 ExecuteService ... 290
15.8.3.4 GetServiceProviderEventValues ... 292
15.8.3.5 SetProperty ... 293
15.8.3.6 TerminateService ... 294

15.9 Terms ... 294
15.9.1 Overview ... 294
15.9.2 Syntax ... 294
15.9.3 Semantics for Enumeration terms ... 296
15.9.3.1 PropertyFlagLiteral ... 296
15.9.3.2 PropertyFlagTerm ... 296
15.9.3.3 PropertyFlagValue ... 296
15.9.4 Semantics for External Service provider event query terms ... 297
15.9.4.1 GetServiceProviderFromEvent ... 297
15.9.4.2 IsServiceExecutionFinishedEvent ... 297
15.9.4.3 IsServiceProviderEvent ... 297
15.9.5 Semantics for External service provider event source terms ... 298
15.9.5.1 ServiceExecutionFinishedEventSource ... 298
15.9.5.2 ServiceProviderEventSource ... 299
15.9.6 General Semantics ... 299
15.9.6.1 GetProperty ... 299
15.9.6.2 IsDisposed ... 300
15.9.6.3 IsServiceRunning ... 300
15.9.6.4 ServiceProviderTerm ... 301
15.9.6.5 ServiceProviderValue ... 301
15.9.6.6 ServiceTerm ... 302
15.9.6.7 ServiceValue ... 302

16 OTX File Extension 303

16.1 Introduction ... 303

16.2 Datatypes ... 303
16.2.1 Overview ... 303
16.2.2 Syntax ... 303
16.2.3 Semantics ... 304
16.2.3.1 FileHandle ... 304
16.2.3.2 FileReadHandle ... 305
16.2.3.3 FileWriteHandle ... 305

16.3 Exceptions ... 305
16.3.1 Overview ... 305
16.3.2 Syntax ... 305

16.3.3 Semantics 306
16.3.3.1 General 306
16.3.3.2 FileAccessException 306
16.3.3.3 FileException 306
16.3.3.4 FileFormatException 307
16.3.3.5 FileLockException 307
16.3.3.6 FileNotFoundException 307
16.3.3.7 FileOpenException 307
16.3.3.8 FileSaveException 307
16.4 Variable access 307
16.4.1 Overview 307
16.4.2 Syntax 307
16.4.3 Semantics 308
16.5 Actions 308
16.5.1 Overview 308
16.5.2 Syntax 309
16.5.3 General Semantics 311
16.5.3.1 CloseFile 311
16.5.3.2 DeleteDirectory 311
16.5.3.3 DeleteFile 311
16.5.3.4 SaveFile 312
16.5.3.5 WriteBytes 312
16.5.3.6 WriteFile 313
16.5.3.7 WriteLine 313
16.6 Terms 314
16.6.1 Overview 314
16.6.2 Syntax 314
16.6.3 General Semantics 316
16.6.3.1 CreateTempDirectory 316
16.6.3.2 FileHandleTerm 316
16.6.3.3 FileReadHandleTerm 316
16.6.3.4 FileReadHandleValue 316
16.6.3.5 FileWriteHandleTerm 317
16.6.3.6 FileWriteHandleValue 317
16.6.3.7 GetFilePath 317
16.6.3.8 GetFilesFromDirectory 318
16.6.3.9 GetFileSize 319
16.6.3.10 IsDirectory 319
16.6.3.11 IsEndOfFileReached 320
16.6.3.12 IsFile 320
16.6.3.13 OpenFileForRead 320
16.6.3.14 OpenFileForWrite 321
16.6.3.15 ReadBytes 322
16.6.3.16 ReadFile 323
16.6.3.17 ReadLine 323
17 OTX FlashPlus Extension 325
17.1 Introduction 325
17.2 Exceptions 325
17.2.1 Overview 325
17.2.2 Syntax 325

17.2.3 Semantics 326
17.2.3.1 General 326
17.2.3.2 FlashPlusException 326
17.3 Actions 326
17.3.1 Overview 326
17.3.2 Syntax 326
17.3.3 General Semantics 327
17.3.3.1 SetActiveFile 327
17.4 Terms 328
17.4.1 Overview 328
17.4.2 Syntax 328
17.4.3 General Semantics 329
17.4.3.1 GetActiveFileName 329
17.4.3.2 GetFlashDataFileNames 329
17.4.3.3 GetOwnIdentFromComChannel 330
17.4.3.4 IsLateBound 330
18 OTX Persistence Extension 332
18.1 Introduction 332
18.2 Exceptions 332
18.2.1 Overview 332
18.2.2 Syntax 332
18.2.3 Semantics 333
18.2.3.1 General 333
18.2.3.2 PersistenceException 333
18.2.3.3 PersistenceSaveException 333
18.3 Actions 334
18.3.1 Overview 334
18.3.2 Syntax 334
18.3.3 General Semantics 334
18.3.3.1 Load 334
18.3.3.2 Save 335
19 OTX SQL Extension 336
19.1 Introduction 336
19.2 Datatypes 336
19.2.1 Overview 336
19.2.2 Syntax 337
19.2.3 Semantics 337
19.2.3.1 Connection 337
19.2.3.2 ResultSet 337
19.3 Exceptions 338
19.3.1 Overview 338
19.3.2 Syntax 338
19.3.3 Semantics 339
19.3.3.1 General 339
19.3.3.2 CommandException 339
19.3.3.3 ConnectionException 339
19.3.3.4 SqlException 339

19.4 Variable access 339
19.4.1 Overview 339
19.4.2 Syntax 339
19.4.3 Semantics 340
19.5 Actions 340
19.5.1 Overview 340
19.5.2 Syntax 340
19.5.3 General Semantics 341
19.5.3.1 CloseConnection 341
19.5.3.2 ExecuteQuery 341
19.5.3.3 ExecuteUpdate 342
19.6 Terms 343
19.6.1 Overview 343
19.6.2 Syntax 343
19.6.3 General Semantics 343
19.6.3.1 ConnectionTerm 343
19.6.3.2 ConnectionValue 343
19.6.3.3 CreateConnection 344
19.6.3.4 GetResultValueAsBoolean 344
19.6.3.5 GetResultValueAsByteField 345
19.6.3.6 GetResultValueAsFloat 346
19.6.3.7 GetResultValueAsInteger 347
19.6.3.8 GetResultValueAsString 347
19.6.3.9 NextResult 348
19.6.3.10 ResultSetTerm 349
19.6.3.11 ResultSetValue 349
20 OTX StateMachineProcedure Extension 350
20.1 Introduction 350
20.2 Datatypes 352
20.2.1 Overview 352
20.2.2 Syntax 352
20.2.3 Semantics 353
20.2.3.1 State 353
20.2.3.2 States 353
20.2.3.3 Transition 354
20.2.3.4 Transitions 354
20.2.3.5 Trigger 355
20.2.3.6 TriggerRef 355
20.2.3.7 TriggerRefs 355
20.2.3.8 Triggers 355
20.3 Procedures 356
20.3.1 Overview 356
20.3.2 Syntax 356
20.3.3 General Semantics 357
20.3.3.1 StateMachineProcedure 357
20.3.3.2 StateMachineProcedureRealisation 359
21 OTX StateVariable Extension 361
21.1 Introduction 361

21.2 Declaration and Arguments 361
21.2.1 Syntax 361
21.2.2 Semantics 362

22 OTX TestResultHandling Extension 363

22.1 Introduction 363

22.2 Datatypes 363
22.2.1 Overview 363
22.2.2 Syntax 363
22.2.3 Semantics 364
22.2.3.1 TestResultContainer 364
22.2.3.2 TestResultHandlingLevel 365
22.2.3.3 TestResultSession 365
22.2.3.4 TestResultSeverity 365
22.2.3.5 TestResultState 366

22.3 Enumerations 367
22.3.1 Overview 367
22.3.2 Syntax 367
22.3.3 Semantics 367
22.3.3.1 TestResultHandlingLevels 367
22.3.3.2 TestResultSeverities 367
22.3.3.3 TestResultStates 368

22.4 Exceptions 368
22.4.1 Overview 368
22.4.2 Syntax 368
22.4.3 Semantics 369
22.4.3.1 General 369
22.4.3.2 TestResultContainerException 369
22.4.3.3 TestResultException 369
22.4.3.4 TestResultHandlingException 369
22.4.3.5 TestResultSaveException 370
22.4.3.6 TestResultSessionException 370

22.5 Variable access 370
22.5.1 Overview 370
22.5.2 Syntax 370
22.5.3 Semantics 371

22.6 Declaration and Arguments 371
22.6.1 Syntax 371
22.6.2 Semantics 372

22.7 Actions 372
22.7.1 Overview 372
22.7.2 Syntax 372
22.7.3 General Semantics 374
22.7.3.1 AddFileToTestResult 374
22.7.3.2 AddInfoToTestResult 374
22.7.3.3 CloseTestResultSession 375
22.7.3.4 MultipleLimit 375
22.7.3.5 MultipleOrSingleLimit 376
22.7.3.6 SetDtcTestResult 376
22.7.3.7 SetEqualityTestResult 377

22.7.3.8 SetListTestResult ... 378
22.7.3.9 SetMapTestResult ... 380
22.7.3.10 SetTestResult ... 381
22.7.3.11 SetTestResultHandlingLevel ... 381
22.7.3.12 SetTestResultState ... 381
22.7.3.13 SetToleranceTestResult ... 382
22.7.3.14 SetValueTestResult ... 383

22.8 Terms ... 384
22.8.1 Overview ... 384
22.8.2 Syntax ... 384
22.8.3 Semantics for Enumeration Terms ... 385
22.8.3.1 GetTestResultState ... 385
22.8.3.2 TestResultHandlingLevelLiteral ... 386
22.8.3.3 TestResultHandlingLevelTerm ... 386
22.8.3.4 TestResultHandlingLevelValue ... 386
22.8.3.5 TestResultSeverityLiteral ... 387
22.8.3.6 TestResultSeverityTerm ... 387
22.8.3.7 TestResultSeverityValue ... 387
22.8.3.8 TestResultStateLiteral ... 388
22.8.3.9 TestResultStateTerm ... 388
22.8.3.10 TestResultStateValue ... 388
22.8.4 General Semantics ... 389
22.8.4.1 GetTestResultContainerByName ... 389
22.8.4.2 GetTestResultSession ... 389
22.8.4.3 TestResultContainerTerm ... 390
22.8.4.4 TestResultContainerValue ... 390
22.8.4.5 TestResultSessionTerm ... 391
22.8.4.6 TestResultSessionValue ... 391

23 OTX Util Extension 392

23.1 Introduction ... 392

23.2 Exceptions ... 392
23.2.1 Overview ... 392
23.2.2 Syntax ... 392
23.2.3 Semantics ... 393
23.2.3.1 General ... 393
23.2.3.2 StringFormatException ... 393
23.2.3.3 UtilException ... 393

23.3 Terms ... 394
23.3.1 Overview ... 394
23.3.2 Syntax ... 394
23.3.3 Semantics for Util Terms ... 396
23.3.3.1 Compare ... 396
23.3.3.2 CopyByteField ... 396
23.3.3.3 GetRandomNumber ... 396
23.3.3.4 IsInitialized ... 397
23.3.3.5 ListIndexOf ... 397
23.3.3.6 ListIndexOfAny ... 397
23.3.3.7 ListReverse ... 398
23.3.3.8 ListSort ... 398
23.3.3.9 Max ... 399
23.3.3.10 Min ... 399

23.3.3.11 StringFormat ... 400

24 OTX VehicleInfo Extension 402

24.1 Introduction ... 402

24.2 Datatypes ... 402
24.2.1 Overview ... 402
24.2.2 Syntax ... 402
24.2.3 Semantics ... 402
24.2.3.1 GatewayMode ... 402

24.3 Enumerations ... 403
24.3.1 Overview ... 403
24.3.2 Syntax ... 403
24.3.3 Semantics ... 403
24.3.3.1 GatewayModes ... 403

24.4 Exceptions ... 404
24.4.1 Overview ... 404
24.4.2 Syntax ... 404
24.4.3 Semantics ... 405
24.4.3.1 General ... 405
24.4.3.2 GatewayException ... 405
24.4.3.3 VehicleInfoException ... 405

24.5 Variable access ... 405
24.5.1 Overview ... 405
24.5.2 Syntax ... 405
24.5.3 Semantics ... 406

24.6 Terms ... 406
24.6.1 Overview ... 406
24.6.2 Syntax ... 406
24.6.3 General Semantics ... 407
24.6.3.1 GatewayModeLiteral ... 407
24.6.3.2 GatewayModeTerm ... 408
24.6.3.3 GatewayModeValue ... 408
24.6.3.4 GetDbComChannelDbComChannelsOfGateways ... 408
24.6.3.5 GetDbComChannelGatewayMode ... 409
24.6.3.6 IsDbComChannelAccessedViaGateway ... 409

25 OTX XML Extension 410

25.1 Introduction ... 410

25.2 Datatypes ... 410
25.2.1 Overview ... 410
25.2.2 Syntax ... 410
25.2.3 Semantics ... 411
25.2.3.1 XmlDocument ... 411
25.2.3.2 XmlElement ... 411

25.3 Exceptions ... 411
25.3.1 Overview ... 411
25.3.2 Syntax ... 411
25.3.3 Semantics ... 412
25.3.3.1 General ... 412

25.3.3.2 XmlChangeException ... 412
25.3.3.3 XmlException ... 412
25.3.3.4 XmlFormatException ... 412
25.3.3.5 XPathException ... 412
25.4 Variable access ... 413
25.4.1 Overview ... 413
25.4.2 Syntax ... 413
25.4.3 Semantics ... 413
25.5 Actions ... 414
25.5.1 Overview ... 414
25.5.2 Syntax ... 414
25.5.3 General Semantics ... 416
25.5.3.1 AddXmlChildElement ... 416
25.5.3.2 DeleteXmlAttribute ... 416
25.5.3.3 DeleteXmlChildElement ... 416
25.5.3.4 SetXmlComment ... 417
25.5.3.5 SetXmlElementAttribute ... 417
25.5.3.6 SetXmlElementAttributes ... 418
25.5.3.7 SetXmlElementText ... 418
25.5.3.8 SetXmlProcessingInstructions ... 418
25.5.3.9 ValidateXml ... 419
25.5.3.10 XmlSaveToFile ... 419
25.6 Terms ... 420
25.6.1 Overview ... 420
25.6.2 Syntax ... 420
25.6.3 General Semantics ... 422
25.6.3.1 CopyXmlElement ... 422
25.6.3.2 CreateXmlDocument ... 422
25.6.3.3 CreateXmlElement ... 422
25.6.3.4 GetXmlElementAttributes ... 423
25.6.3.5 GetXmlElementChildElements ... 423
25.6.3.6 GetXmlElementName ... 424
25.6.3.7 GetXmlElementsByXPath ... 424
25.6.3.8 GetXmlElementText ... 425
25.6.3.9 GetXmlRootElement ... 425
25.6.3.10 XmlDocumentTerm ... 425
25.6.3.11 XmlDocumentValue ... 426
25.6.3.12 XmlElementTerm ... 426
25.6.3.13 XmlElementValue ... 426
25.6.3.14 XmlFromByteField ... 427
25.6.3.15 XmlLoadFromFile ... 427
25.6.3.16 XmlToByteField ... 428
26 OTX ZipHandling Extension 429
26.1 Introduction ... 429
26.2 Exceptions ... 429
26.2.1 Overview ... 429
26.2.2 Syntax ... 429
26.2.3 Semantics ... 430
26.2.3.1 General ... 430
26.2.3.2 FileAlreadyExistsException ... 430

26.2.3.3 FileNotFoundException ... 430
26.2.3.4 ZipFormatException ... 431
26.2.3.5 ZipHandlingException ... 431

26.3 Actions ... 431
26.3.1 Overview ... 431
26.3.2 Syntax ... 431
26.3.3 General Semantics ... 432
26.3.3.1 UnZipFile ... 432
26.3.3.2 ZipFile ... 434

27 Terms and Definitions 437

28 Symbols and Abbreviated Terms 438

29 Bibliography 439

Appendix: A. Comprehensive checker rule listing 440

A.1. Overview ... 440

A.2. Listing ... 440
A.2.1. Checker rules for BusMonitoring Extension ... 440
A.2.1.1. BusMonitoring_Chk001 – correct element types for adresses list in StartBusMonitoring ... 440
A.2.2. Checker rules for CommonDialogs Extension ... 440
A.2.2.1. CommonDialogs_Chk001 – Type-safe FileOpenDialog ... 440
A.2.3. Checker rules for DataType Extension ... 440
A.2.3.1. DataType_Chk001 – Accessing structure elements ... 440
A.2.3.2. DataType_Chk002 – Correct target for Enumeration ... 440
A.2.3.3. DataType_Chk003 – No Circular type definitions of Structures ... 441
A.2.3.4. DataType_Chk004 – No mixture of implicit and explicit enumeration values ... 441
A.2.4. Checker rules for DiagComPlus Extension ... 441
A.2.4.1. DiagComPlus_Chk001 – correct element types for responses map ... 441
A.2.5. Checker rules for ExternalServiceProvider Extension ... 441
A.2.5.1. ExternalServiceProvider_Chk001 – Correct target for service provider ... 441
A.2.5.2. ExternalServiceProvider_Chk002 – Correct CreateProvider constructor arguments ... 441
A.2.5.3. ExternalServiceProvider_Chk003 – Input argument omission ... 442
A.2.5.4. ExternalServiceProvider_Chk004 – Correct CreateProvider constructor reference ... 442
A.2.5.5. ExternalServiceProvider_Chk005 – Correct ExecuteService service reference ... 442
A.2.5.6. ExternalServiceProvider_Chk006 – Correct ExecuteService arguments ... 442
A.2.5.7. ExternalServiceProvider_Chk007 – Correct property attribute reference ... 442
A.2.5.8. ExternalServiceProvider_Chk008 – Correct Property access ... 442

A.2.5.9. ExternalServiceProvider_Chk009 – Correct event attribute reference 442
A.2.5.10. ExternalServiceProvider_Chk010 – Correct CreateProvider constructor attribute..... 443
A.2.5.11. ExternalServiceProvider_Chk011 – Correct Event values 443
A.2.6. Checker rules for Persistence Extension..... 443
A.2.6.1. Persistence_Chk001 – PersistableDataTypes 443
A.2.7. Checker rules for SQL Extension 443
A.2.7.1. SQL_Chk001 – Right column data type 443
A.2.8. Checker rules for StateMachine Extension..... 443
A.2.8.1. StateMachineProcedure_Chk001 – No Procedure realization 443
A.2.8.2. StateMachineProcedure_Chk002 – Mandatory target state..... 443
A.2.8.3. StateMachineProcedure_Chk003 – No target state for completed state 443
A.2.8.4. StateMachineProcedure_Chk004 – Mandatory trigger..... 443
A.2.8.5. StateMachineProcedure_Chk005 – Mandatory transition. 444
A.2.8.6. StateMachineProcedure_Chk006 – Initial and completed state shall be distinguished 444
A.2.8.7. StateMachineProcedure_Chk007 – Correct nesting of initial state..... 444
A.2.8.8. StateMachineProcedure_Chk008 – Correct nesting of completed state 444
A.2.8.9. StateMachineProcedure_Chk009 – Correct nesting of transition target state 444
A.2.8.10. StateMachineProcedure_Chk010 – Correct nesting of transition trigger references 444
A.2.8.11. StateMachineProcedure_Chk011 – unreachable states... 444
A.2.9. Checker rules for StateVariable Extension 444
A.2.9.1. StatVar_Chk001 – State variables shall not read 444
A.2.10. Checker rules for TestResultHandling Extension 444
A.2.10.1. TestResultHandling_Chk001 – type safe list comparison. 444
A.2.10.2. TestResultHandling_Chk002 – correct list type for DTC's list 445
A.2.10.3. TestResultHandling_Chk003 – correct element types for properties map..... 445
A.2.10.4. TestResultHandling_Chk004 – correct list type for SetListTestResult..... 445
A.2.10.5. TestResultHandling_Chk005 – correct map type for SetMapTestResult 445
A.2.11. Checker rules for Util Extension 445
A.2.11.1. Util_Chk001 – For the ListSort term the item Type of the list shall be of SimpleType 445
A.2.12. Checker rules for Xml Extension 445
A.2.12.1. Xml_Chk001 – type-safe SetXmlElementAttributes..... 445
A.2.12.2. Xml_Chk002 – type-safe CreateXmlElement 446
A.2.12.3. Xml_Chk003 – type-safe GetXmlElementAttributes 446
A.2.13. Checker rules for ZipFiles Extension..... 446
A.2.13.1. ZipFiles_Chk001 – type-safe UnZipFile 446
A.2.13.2. ZipFiles_Chk002 – type-safe ZipFile..... 446

Appendix: B. PTX File 447

B.1. Introduction 447
B.2. Security 448
B.2.1. Requirements 448
B.2.2. Solution 448
B.2.3. Signing PTX for transport 449
B.2.3.1. Overview 449
B.2.3.2. Process 449
B.2.3.3. Pseudo-code 449
B.2.4. Verifying PTX against manipulation 450
B.2.4.1. Overview 450
B.2.4.2. Process 450
B.2.4.3. Pseudo-code 452
B.2.5. Preparing the PTX content digest 452
B.2.5.1. Overview 452
B.2.5.2. Process 452
B.2.5.3. Pseudo-code 454
B.3. PTXDataModel 454
B.3.1. PTX data model schema 454
B.3.2. PTX data model include schema 459

Appendix: C. TestResultDataModel 462

C.1. TestResult data model 462
C.1.1. TestResult data model schema 462
C.1.2. TestResult data model example 463
C.2. TestResult XML instance 465
C.2.1. TestResult XML instance schema 465
C.2.2. TestResult XML instance example 466

Appendix: D. Test Sequence Examples 468

D.1. Assertion 468
D.1.1. Assertion Example 468
D.2. BlackBox 469
D.2.1. BlackBox Pseudocode 469
D.2.2. BlackBox Example 469
D.3. BusMonitoring 471
D.3.1. BusMonitoring Example 471
D.4. ComInterface 474
D.4.1. ComInterface Pseudocode 474
D.4.2. ComInterface Example 475
D.5. CommonDialogs 480
D.5.1. CommonDialogs Example 480
D.5.1.1. FileOpenDialog 480
D.6. DataTypes 482
D.6.1. DataTypes Example 482
D.7. DiagComPlus 485
D.7.1. DiagComPlus Example 485
D.8. DiagConfiguration 487

D.8.1. DiagConfiguration Pseudocode 487
D.8.2. DiagConfiguration Example 487
D.9. DiagDataBrowsingPlus 489
D.9.1. DiagDataBrowsingPlus Pseudocode 489
D.10. ECUConfiguration 490
D.10.1. ECUConfiguration Pseudocode 490
D.10.2. ECUConfiguration Example 491
D.11. EventPlus 497
D.11.1. EventPlus Example 497
D.12. ExternalServiceProvider 499
D.12.1. ExternalServiceProvider Example 499
D.13. File 505
D.13.1. File Example 505
D.14. FlashPlus 506
D.14.1. FlashPlus Example 506
D.15. Persistence 508
D.15.1. Persistence Example 508
D.16. SQL 510
D.16.1. SQL Pseudocode 510
D.17. StateMachineProcedure 511
D.17.1. StateMachineProcedure Example 511
D.18. StateVariable 513
D.18.1. StateVariable Example 513
D.19. TestResultHandling 514
D.19.1. TestResultHandling Pseudocode 514
D.19.2. TestResultHandling Example 514
D.20. Util 518
D.20.1. Util Example 518
D.21. VehicleInfo 519
D.21.1. VehicleInfo Example 519
D.22. XML 520
D.22.1. XML Pseudocode 520
D.23. ZIPHandling 521
D.23.1. ZIPHandling Example 521
Figure Directory 523
Table Directory 526

Foreword

ISO 13209 consists of the following parts, under the general title Road vehicles — Open Test sequence eXchange format (OTX):

— *Part 1: General information and use cases*

— *Part 2: Core data model specification and requirements*

— *Part 3: Standard extensions and requirements*

— *Part 4: Extension interface definition*